

## **FLEXWALL ASSEMBLY INSTRUCTIONS:**

1. Ground Preparation – Fill in deep contours, such as wheel ruts. To avoid punctures and tears, remove any sharp objects from the ground, including rocks or other sharp debris.
2. Roll out Ground Mat protection, if available.
3. Unfold berm and position over ground mat.
4. Slide together snap supports on both sides.
5. Install white plugs (provided in repair kit) into drain assembly on berm.
6. Depending on weather conditions, determine if berm should be secured with sandbags or staked to the ground.

## **PRECAUTIONS:**

- All materials have limitations. Ensure the bottoms of skids are free of gravel, debris and any sharp edges prior to placing on berm.
- **DO NOT** drive on the yellow brackets as they will break.
- Avoid skidding the unit on the berm.

## **SAFETY:**

Consider slips, trips and falls while working on/in the berm. Fabric can be very slippery when wet or icy and yellow brackets may cause tripping hazards.