

THROW SNAP ASSEMBLY INSTRUCTIONS:

1. Ground Preparation – Fill in deep contours, such as wheel ruts. To avoid punctures and tears, remove any sharp objects from the ground, including rocks or other sharp debris.
2. Roll out Ground Mat protection, if available.
3. Unfold berm and position over ground mat.
4. Check to ensure berm is properly positioned.
5. Install white plugs (provided in repair kit) into drain assembly on berm.
6. Place vehicle or object inside berm.
7. From the corner of the berm, find rods at three foot intervals. Firmly pull up on rods to snap into place.
8. Depending on weather conditions, determine if berm should be secured with sandbags or staked to the ground.

PRECAUTIONS:

- All materials have limitations. Ensure the bottoms of skids are free of gravel, debris and any sharp edges prior to placing on berm.
- Avoid skidding the unit on the berm.

SAFETY:

Consider slips, trips and falls while working on/in the berm. Fabric can be very slippery when wet or icy.